

# ACCESSORIES TRIAC DRIVE PID



## Pressure roller for TRIAC DRIVE



115.274: Pressure roller 12 mm

115.176: Pressure roller 30 mm

115.186: Pressure roller 38 mm

## Guide handle for TRIAC DRIVE



115.284: Guide handle

## Single supporting carrier for TRIAC DRIVE



115.276: Single supporting carrier

## Double supporting carrier for TRIAC DRIVE



115.275: Double supporting carrier

## Overlap welding nozzle with/without grip, inside push-fit on TRIAC DRIVE



115.283: Overlap welding nozzle 12 mm, with grip, inside, push-fit

115.279: Overlap welding nozzle 30 mm, with grip, inside, push-fit

115.281: Overlap welding nozzle 38 mm, with grip, inside, push-fit

115.699: Overlap welding nozzle 12 mm, without grip, inside, push-fit

115.701: Overlap welding nozzle 30 mm, without grip, inside, push-fit

115.703: Overlap welding nozzle 38 mm, without grip, inside, push-fit

## **Overlap welding nozzle with/without grip, outside push-fit on TRIAC DRIVE**



**115.282:** Overlap welding nozzle 12 mm, with grip, outside, push-fit

**115.278:** Overlap welding nozzle 30 mm, with grip, outside, push-fit

**115.280:** Overlap welding nozzle 38 mm, with grip, outside, push-fit

**115.698:** Overlap welding nozzle 12 mm, without grip, outside, push-fit

**115.700:** Overlap welding nozzle 30 mm, without grip, outside, push-fit

**115.702:** Overlap welding nozzle 38 mm, without grip, outside, push-fit